



REINIGUNG VON MIT SPLITTERSCHUTZLACK ÜBERZOGENEN FLÄCHEN:

EMPFOHLENE REINIGUNGSMETHODEN:

- ABWASCHEN MIT HAUSHALTSÜBLICHEN REINIGUNGSMITTELN. ZUR NEUTRALISATION DIE FLÄCHE ANSCHLIEßEND NOCHMAL ABSPÜLEN
- REINIGEN MITTELS HOCHDRUCKREINIGER (MINDESTABSTAND 20CM)

DA DER SPLITTERSCHUTZLACK GRUNDSÄTZLICH KEINE KRATZUNEMPFLINDLICHE OBERFLÄCHE BESITZT, SOLLTEN SIE AUF KEINEN FALL SCHARFKANTIGE ODER SCHEUERENDE REINIGUNGSMITTEL VERWENDEN.

EBENSO KANN DER EINSATZ VON HOCHKONZENTRIERTEN SÄUREN, LAUGEN UND LÖSEMITLEN DIE BESCHICHTUNG BESCHÄDIGEN. EINE GENAUE AUFLISTUNG IST NICHT MÖGLICH.

RECOMMENDED CLEANING METHODS:

- WASH WITH COMMON HOUSEHOLD CLEANING AGENTS THEN RINSE THE SURFACE AGAIN TO NEUTRALIZE IT
- CLEANING WITH A HIGH PRESSURE CLEANER (MINIMUM DISTANCE 20CM)

SINCE THE SPLINTER PROTECTION LACQUER IS BASICALLY NOT A SCRATCH-RESISTANT SURFACE YOU SHOULD NEVER USE SHARP OR ABRASIVE CLEANING AGENTS.

THE USE OF HIGHLY CONCENTRATED ACIDS, ALKALIS AND SOLVENTS DAMAGE THE COATING. A PRECISE LISTING IS NOT POSSIBLE.